

## Package Contains:

1. Rocketik with preassembled RouterBoard
2. PoE Adapter /optional/



Your Rocketik contains preassembled RouterBoard with connected pigtails. For First use of the board, powering, booting and board descriptions, please follow instructions on [routerboard.com](http://routerboard.com):

- <http://routerboard.com/RB711-5HnD>
- <http://routerboard.com/RB711G-5HnD>
- <http://routerboard.com/RB711UA-5HnD>
- <http://routerboard.com/RB711GA-5HnD>
- <http://routerboard.com/RB711UA-2HnD>

## Installation of Rocketik

You can easily snap Rocketik to compatible Antenna. Please refer to our webpage [www.rfelements.com](http://www.rfelements.com) to check updated list of compatible antennas.



## How to Remove the Rocketik

To remove Rocketik from the mount, use tool to release the mount's lock. Any firm object that fits the gap could be used: screwdriver, wrench, knife etc.



## RF elements Accessories

For installation on the Wall or Pole, use RF elements Bracket, bracket compatible with Rocketik, Rocket and StationBox Mikro.

